



Model HT-2EZ 2 Wheeled Hose Truck Easy Assembly

Unpack the carton and check for the following hardware:

2 Wheeled Hose Truck Parts

- One (1) Reel Crank Handle
- One (1) Upper Frame
- One (1) Reel Assembly
- One (1) Lower Frame
- Two (2) Tires
- Two (2) Axle Bolt & Nut Assemblies
- One (1) Lead Hose

Assembly Instructions

- 1) Attach the Reel Crank Handle onto the crank shaft located on the Reel Assembly.
- 2) Slide the Reel Assembly over the Lower Frame receivers past the snap lock pins. The Lower Frame receivers will still be visible.
- 3) Slide the Upper Frame over the Lower Frame receivers, locking all three pieces in place.
- 4) Using the Axle Bolt & Nut Assemblies attach the tires through the axle bolt receivers located on the Lower Frame and tighten.

