

Unpack the carton and check for the following hardware:

2 Wheeled Hose Truck Parts

- One (1) Reel Assembly
- One (1) Handle and Set Screw
- One (1) Cushion Crank Grip
- Two (2) Solid Rubber Tires
- Two (2) Axle Bolts & Nut Assemblies
- One (1) Leader Hose

Assembly Instructions

- 1) Attach the Cushion Crank Grip into the receiver tab on the front of the Reel Assembly.
- 2) Slide the Upper Handle on to the Reel Assembly. Tighten set screw.
- 3) Using the Axle Bolt & Nut Assemblies attach the tires through the lower frame of the Reel Assembly
- 4) Attach Lead Hose to inlet pipe. Tighten to ensure a leak free connection.

